

CONCEPT MODELS


Web Address: <http://www.con-sys.com>
Email: concept_models@con-sys.com

8810 El Toro Way
Stockton, CA 95210



**INSTRUCTIONS FOR PRODUCT
SMX 403, CTHX 007, PDTX 205, AMCX 403, GEX 40005
DEPRESSED CENTER FLAT CAR**

SMX 403, CTHX 007, PDTX 205, AMCX 403, GEX 40005 FLAT CAR



Item No.	PART NO.	DESCRIPTION	QTY.
1	7029-1	Floor Beam	2
2	7029-2	Left Lift Girder Face	2
3	7029-3	Right Lift Girder Face	2
4	7029-4	Lift Girder Core	2
5	7029-5	Floor Core	1
6	7029-6	Truck Bolster Deck	2
7	7029-7	Truck Bolster Bottom	2
8	7029-8	Truck Bolster Top	2
9	B-25	End Sill	2
10	7029-10	"X" Brace	2
11	7029-11	Girder end	4
12	1089	Aux. Air Tank. (Long)	1
13	7029-13	Girder End Brace	2


	GENERIC PARTS	QTY.
	1/8" Tube x 3 s.f.	2
1013	1/8" x 2-56 screws	2
1018	Brake Valve	2
1020	Brake Reservoir	2
1010	Brake Wheel	2
1021	Brake Stand	2
1011	Small Pins	6
1012	Coupler Covers	2
	Decals	1
	Instructions	1

Tools

All basic model workers tools – files, motor-tool with fine burrs, hobby knife, Wood blocks for holding parts square, metal square, etc.

Drills: 1/8", #76, #72, #68, #50 (2-56 tap drill), #65

Music Wire .020" for handrails. Athearn stanchions for tanks cars.



This fixture is a great aid to assembly. It helps hold parts square while gluing and aids in drawing horizontal lines on tanks for tank cars.

Instructions

NOTE: This kit consists of resin castings and must be assembled with an ACC cement (not provided) – both the thicker types as well as the thin. Solvent cements will **NOT** bond the parts together! They can dissolve them. Resin parts are more fragile than common styrene plastic used in injection molded models. Use reasonable care in handling and do not apply any solvents. The illustrations at the front show the general layout of parts for the car. Work very carefully when positioning the parts for gluing. ACC cements adhere very quickly and permanently.

Gluing with ACC Cements – USE WITH CARE

ACC cements allow the modeler to work very quickly. A general rule is to use the thin cements to glue long joints taking advantage of capillary action that makes the cement run the length of the seam. The thicker cement is suited to applying large area parts to each other. An accelerator can be applied sparingly. One technique is to apply the glue to one part and the accelerator to the other part to be joined. I also use a Q-tip to apply a minute amount of accelerator to the glue after the parts have been joined. The accelerator triggers the ACC cement to set very quickly. It is only slightly slower with the thicker cement.


WARNING

Some parts have lead encapsulated within them. In the event the lead is exposed for any reason, do not allow it to remain on the skin. Dispose of any lead shavings that may result. Obey all safety precautions of all suggested cements and assembly materials.






PREPARATION Wash the parts before assembling with a dish washing detergent such as “Dawn”. Rub lightly with a soft sponge.

ASSEMBLY

1 Apply the Bolster Decks to the coupler end of the truck bolsters as shown. After the cement is set, drill a 1/8" hole no more than half the thickness of the bolster from the **TOP**. Work carefully. Use a pin vise if you do not have a drill press with stops. Install the 1/8" tube and then attach the Bolster Tops as shown.




2 Add the brake wheel to the brake stand with the small pin provided. Attach the end fascia and then cement the a brake stand assembly to each car end as shown. Add the brake valve, break reservoir and auxiliary air tank as shown to the B end of the car. If you wish to add piping, the adjacent photo is the only information we have. My choice is always .015 steel since it resists bending once the model is finished and placed in operation.




5 A fixture as we describe on page 3 is a great aid for the following steps. Cement the Left Lift Girder Face (2) exactly flush with the end and the top of the Floor Core (5). Do the same with the Right Lift Girder Face (3). Make both ends the same.



6 Turn the floor core with the best side facing down then attach the Floor Beams (1) to each side of the Floor Core (5) wide edge down. Make sure that the Floor Beams are centered evenly on the floor core.




7 Cement the car ends to the floor sub assembly. You will have to trim slightly to get the assemblies to go together without leaving any gaps. Make sure that the tops of the ends are parallel to the floor and that both ends have the same elevation.



8 After the cement is firmly set, turn the girder assembly over and mark $3/16''$ from the end in the center and drill a $1/8''$ hole clear through.



9 Install the "X" braces as shown. Install the Girder End close to the $1/8''$ hole as possible without interfering with the $1/8''$ tube for attaching the bolsters.



10 . Install 6-wheel Buckeye trucks as shown. Drill a #76 hole and place a small pin as shown to keep the trucks from swiveling when placing on the track. Trim pin to clear.



11 After installing couplers, place the girder assembly on the bolster assemblies.



PAINING

.If you followed the instructions for cleaning the parts before assembly, you are ready to paint. A primer is recommended. Allow to dry overnight before proceeding with any of the color coats. When painting with white do not over dilute with thinner. Two coats with plenty of drying time in between are recommended. White on top of primer is recommended for light colors yellow through red. It improves the color. After painting, overcoat entire car with Testor's Glosscote prior to decaling. If you decal over the Glosscote as soon as it is just dry to the touch, decal adhesion is improved.

COLORS	
SMAX 403	BLUE BOLSTER ENDS, ORANGE GIRDER ASSEMBLY
ACMX 403	BLACK, GRAY, OR BLUE DEPENDING ON PERIOD
CTHX 007	MEDIUM BLUE
PTDX 205	GRAY
	SEE ONLINE COPY OF THIS SHEET FOR COLOR PHOTO

DECALING

The decals provided are a very thin film decal film. Success with these decals depends on following these instructions.

- 1) Cut out the decal segment you are going to apply.
- 2) Dip the decal in warm water which has had 1 drop of DAWN kitchen detergent. Do not leave the decal to soak in the water.
- 3) Slide the decal directly onto the wetted surface with a small brush. Position with the brush. Remove excess water with a tissue.

NOTE: The glue used for the decal sheet is different than what has been used in the past. The water does not dissolve the glue. Water causes a chemical reaction causing an almost immediate release of the decal. For this reason once the decal has been wetted it must be used quickly. It cannot be re-wetted later for use. Top coat the decals with Testor's Dullcote for best results.



RIGHT REAR

